

UST150P

Analog Signal Converter USERS' GUIDE



DESCRIPTION of the DEVICE

UST150P Model devices are used to convert analog signals that are created in any environment to standart analog signals isolated from input.

These devices are microcontroller based and can be configured easily by using SBA100 USB/UART Converter. All inputs and outputs are isolated.

SAFETY PRECAUTIONS

- Before using the device, please read the warnings below and this guide carefully. The accidents or damages resulting from not following the warnings included in this guide are under user's responsibility.
- This device is intended to be used by qualified personnel in industrial environments, do not use in houselike environments.
- Do not use the device at places where corrosive, flammable and explosive gases exist. Contact points may create electrical discharge and this may cause explosion or fire.
- Do not allow metal fragments or lead wire scraps or liquid matters to fall inside this device. Otherwise fire or electrical shock may happen.
- Take the necessary precautions in order to prevent accidents and damages that may result in case the device gets faulty.
- There is no fuse or switch that brings the device in power down state, these should be added to the system by the user.
- Sensor and signalling cables should not be routed close to the power cables or inductive load cables.
- Before connecting the device, supply voltage must be checked if it is suitable according to the product code.
- Do not power up the device before the connections related with the device are performed in accordance with the connection diagram. While the device is powered, do not touch on the terminals.
- Configuration settings at factory out should be changed according to the user's preferences. The accidents and damages resulting from incorrect configuration settings are under users' responsibility.
- Lifetime of the device is 10 years.
- Never disassemble, repair and modify the device. These should be carried out by


PRODUCT CODE

UST150P- / RS / O1 /

Power Supply:
0 = 100-240Vac/dc (Universal)
1 = 24Vac/dc
Analog Output:
1 = 0/4-20mA Current Output
2 = 0/2-10V Voltage Output
RS 485 MODBUS-RTU
0 = No RS 485
1 = Available

Manufacturer and Technical Service:
ORDEL Ltd. Şti. Uzayçağı Cad. 1252. Sok. No:12 OSTİM/ANKARA

CONNECTION DIAGRAM



TECHNICAL SPECIFICATIONS

Besleme Gerilimi	100-240Vac/dc: +%10 -%15	24Vac/dc: +%10 -%20
Power	3W,5VA	
Pulse Input	15V Lojik (Pulse) Input	
	1-8000 Hz	
	24Vdc (I _{sc} = 30mA)	
Analog Output (O1)	Current: 0/4-20mA, 20-4/0mA (RL ≤ 500Ω) Voltage: 0/2-10V, 10-2/0V (RL ≥ 1MΩ)	
Memory	100 year, 100.000 renewals	
Doğruluk	+/- %0,2	
Sampling Time	100ms	
Environment Temperature	Operation: -10...+55C, Storage: -20...+65C	
Protection	IP20	
Dimensions	Width: 25 mm, Height: 91 mm, Depth: 113 mm	
Weight	134 gr	

COMMUNICATION ADDRESSES

REGISTER Type Parameters (REGISTERS)

Adres	Açıklama	Ayar Aralığı	Çarpan	Birim	Yazma İzni
0	Decimal Point (DP)	0 3	1		Yok
1	Process Value	-1999 9999	10*DP	EU	Yok
60	Analog output below limit value	-1999 9999	1		
61	Analog output above limit value	-1999 9999	1		

Document Number: KK-UST100-

ORDEL

www.ordel.com.tr